

SQR-17A Troubleshooting

1. Turn **OFF** the MAIN power switch at the MARWAY power distribution units, located at the top of the SQR-17a Rack #1 and Rack #2.
 2. Turn the power switch **OFF** at the Digital Processing Unit (**DPU**) and the Post Processing Unit (**PPU**), located at the bottom right corner of the units in SQR-17a Rack #1.
 3. Turn **ON** the main power switch at the MARWAY power distribution units, located at the top of the SQR-17a Rack #1 and Rack #2.
 4. Turn power **ON** at the laptops. (Switch located at the back left-hand side of the units)
 5. After the laptops have finished booting, press **<Ctrl> <Esc>**. (Both buttons at the same time.) This will bring up the **"Task list"** window.
 6. Using the arrow keys select either **Terminal Mode** or **Terminal.PPU.TRM** and **Terminal DPU.TRM** (depending on your system version) and press **<Enter>**.
 7. Select the **"Transfers"** pull down window (**<Alt> <T>**) or mouse button.
 8. Select **"Receive Text File"**
 9. In the **"File Name":** box enter **@ Rack #1 DPU.txt** then press **<Enter>**
@ Rack #2 PPU.txt then press **<Enter>**
 10. If **"Terminal-Error"** window appears: **"Do you want to replace the existing file?"** Press enter to select **"Yes"** to replace file or rename the file to DPU1.txt or PPU1.txt or another naming convention.
 11. At the bottom of the Terminal window you should see either receiving: **PPU.txt** or **DPU.txt** at the respective terminals.
 12. Turn on power to the **PPU** and **DPU**. (You should see activity in both terminal windows)
 13. The system should try to boot normally.
- NOTE:** If the main monitors do not come up or the message **"Standby While Configuring System"** has cleared the screen or after approximately 6 minutes, select **"Stop"** at the bottom left corner of the **"Terminal"** windows at the laptops.
14. Press **<Ctrl> <Esc>** (both buttons at the same time)
 15. Using arrow keys select **"Program Manager"** and press **<Enter>**
 16. Select the **"File Manager"** window in the **"Main "** window.
 17. Using the arrow keys highlight **"Windows"** in the directory tree.
 18. Press **<Tab>** key once.
 19. Using arrow keys scroll down and highlight either **PPU.txt** or **DPU.txt** depending on the workstation.
 20. Insert clean formatted 3 1/2" floppy into disk drive
 21. Press **<F8>** key. In the **I_o** box type **"a:"** then press **<Enter>**
 22. Copy both files onto disk then e-mail to:

John Sadler **sadlerjr@spawar.navy.mil**
BJ Williams **bjwill1@erols.com**